



No.	Part Name	No.	Part Name	No.	Part Name	No.	Part Name
1	Glass	10	Jewel	19	Connection pin	28	Stanchion
2	Hand assy.	11	Center gear	20	Stem	29	Top plate
3	Dial plate	12	Inner ring	21	Lock nut	30	Screw
4	Bezel	13	Tension spring	22	Pivot bearing	31	Back
5	Screw	14	Outer ring	23	Adjustable screw	32	Screw
6	Bear plate	15	Side pin	24	Contact point assy.	33	Sector gear assy.
7	Hair spring pin	16	Bottom pin	25	Bottom plate		
8	Spring stanchion	17	Main body	26	Screw		
9	Spring assy.	18	Dovetail lock nut	27	Plane gear assy.		